



Fitting Instructions

TOWBAR VW74/N
For
Volkswagon Amorak


MATERIALS

A 1 Mainframe
D1 4 M12 x 50mm x 1.5mm 10.9 grade Bolts, Flat Washers and Spring Washers

FITTING

1. Loosely attach Mainframe (A) to lower face of bumper beam using bolts (D1).
2. Ensuring Mainframe (A) is aligned correctly with bumper fully tighten all bolts. (120Nm).

Recommended torque settings: Grade 8.8 bolts: M8 - 24Nm, M10 - 52 Nm, M12 - 80 Nm, M14 - 130 Nm, M16 - 200 Nm
Grade 10.9: M12 - 120Nm, M10 - 70Nm M8- 35Nm



W0001VW74/N-FIT\$01120321000